

Aircraft Make: Garmin GARMIN GNS 530 VHF Communications
Aircraft Model: A92-112A4 Transceiver / VOR/ILS Receiver / GPS Receiver
Aircraft Serial Number: 014

Installation Center: CAA-AL-1114 GARMIN GNS 530 VHF Communications
Transceiver / VOR/ILS Receiver / GPS Receiver

Repair Station # _____
Name: INT AVIONICS SERVICE
Address: 3017 ADAM AIRPORT PL. N. S.W.
WASHPAR AIRPORT NO.

**FAA APPROVED FLIGHT MANUAL SUPPLEMENT
GARMIN GNS 530 VHF COMMUNICATIONS TRANSCIEVER /
VOR/ILS RECEIVER / GPS RECEIVER**

AIRCRAFT MAKE: GARMIN
AIRCRAFT MODEL: A92-112A4
AIRCRAFT SERIAL NO.: 014

This document must be carried in the aircraft at all times. It describes the operating procedures for the GARMIN GNS 530 navigation system when it has been installed in accordance with GARMIN Installation Manual 190-00181-02 Rev. H (Rev. A or later) and FAA Form 337 dated _____.

For aircraft with an FAA Approved Airplane Flight Manual, this document serves as the FAA Approved Flight Manual Supplement for the GARMIN GNS 530. For aircraft that do not have an approved flight manual, this document serves as the FAA Approved Supplemental Flight Manual for the GARMIN GNS 530.

The information contained herein supplements or supersedes the basic Airplane Flight Manual only in those areas listed herein. For limitations, procedures, and performance information not contained in this document, consult the basic Airplane Flight Manual.

FAA APPROVED

Date: _____

Manager, Aircraft Certification Office
Federal Aviation Administration

City: _____, State: _____

FAA APPROVED _____ DATE: _____ PAGE 1 OF 8
190-00181-04 Rev. E

Table of Contents

SECTION	PAGE
GENERAL	3
LIMITATIONS	4
EMERGENCY PROCEDURES	5
NORMAL PROCEDURES	6
PERFORMANCE	8
WEIGHT AND BALANCE	8
AIRPLANE & SYSTEM DESCRIPTIONS	8

FAA APPROVED _____ DATE: _____ PAGE 2 OF 8
190-00181-04 Rev. E

Aircraft Make: Garmin GARMIN GNS 530 VHF Communications
 Aircraft Model: A92-110A9 Transceiver / VOR/ILS Receiver / GPS Receiver
 Aircraft Serial Number: 214

**SECTION II
LIMITATIONS**

- The GARMIN GNS 530 Pilot's Guide, P/N 190-00181-00, Rev. A, dated April 2000 or later appropriate revision must be immediately available to the flight crew whenever navigation is predicated on the use of the system. In addition to the Pilot's Guide, the appropriate Pilot's Guide Addendum also must be immediately available to the flight crew if lightning detection or traffic advisory equipment is interfaced to the system or if primary means oceanic/remote navigation is conducted.
- The GNS 530 must utilize the following or later FAA approved software versions:

Function	Sub-System Version				
	Main	GPS	COM	VOR/LOC	GIS
Initial Approval	2.00	2.00	1.22	1.25	2.00
Traffic / Weather Interface	2.00	2.00	1.22	1.25	2.00
Primary Oceanic/Remote	3.00	3.00	1.22	1.25	2.00
TIS Interface	4.00	2.00	1.22	1.25	2.00

The Main software version is displayed on the GNS 530 self test page immediately after turn-on for 5 seconds. The remaining system software versions can be verified on the AUX group sub-page 2, "Software / Database Versions".

- IFR enroute and terminal navigation predicated upon the GNS 530's GPS Receiver is prohibited unless the pilot verifies the currency of the data base or verifies each selected waypoint for accuracy by reference to current approved data.
- Instrument approach navigation predicated upon the GNS 530's GPS Receiver must be accomplished in accordance with approved instrument approach procedures that are retrieved from the GPS equipment data base. The GPS equipment database must incorporate the current update cycle.
 - Instrument approaches utilizing the GPS receiver must be conducted in the approach mode and Receiver Autonomous Integrity Monitoring (RAIM) must be available at the Final Approach Fix.
 - Accomplishment of ILS, LOC, LOC-BC, LDA, SDF, MLS or any other type of approach not approved for GPS overlay with the GNS 530's GPS receiver is not authorized.

Aircraft Make: Garmin GARMIN GNS 530 VHF Communications
 Aircraft Model: A92-110A9 Transceiver / VOR/ILS Receiver / GPS Receiver
 Aircraft Serial Number: 214

**SECTION I
GENERAL**

- The GNS 530 System is a fully integrated, panel mounted instrument, which contains a VHF Communications Transceiver, a VOR/ILS receiver, and a Global Positioning System (GPS) Navigation computer. The system consists of a GPS antenna, GPS Receiver, VHF VOR/LOC/GS antenna, VOR/ILS receiver, VHF COMM antenna and a VHF Communications Transceiver. The primary function of the VHF Communication portion of the equipment is to facilitate communication with Air Traffic Control. The primary function of the VOR/ILS Receiver portion of the equipment is to receive and demodulate VOR, Localizer, and Glide Slope signals. The primary function of the GPS portion of the system is to acquire signals from the GPS system satellites, recover orbital data, make range and Doppler measurements, and process this information in real-time to obtain the user's position, velocity, and time.
- Provided the GARMIN GNS 530's GPS receiver is receiving adequate usable signals, it has been demonstrated capable of and has been shown to meet the accuracy specifications for:

- VFR/IFR enroute, terminal, and non-precision instrument approach (GPS, Loran-C, VOR, VOR-DME, TACAN, NDB, NDB-DME, RNAV) operation within the U.S. National Airspace System in accordance with AC 20-138.
- One of the approved sensors, for a single or dual GNS 530 installation, for North Atlantic Minimum Navigation Performance Specification (MNPS) Airspace in accordance with AC 91-49 and AC 120-33.
- The system meets RNPS airspace (BRNAV) requirements of AC 90-96 and in accordance with AC 20-138, and JAA AMI 20X2 Leaflet 2 Revision 1, provided it is receiving usable navigation information from the GPS receiver.
- The equipment as installed has been found to comply with the requirements for GPS primary means of navigation in oceanic and remote airspace, when used in conjunction with the 500 Series Trainer Program incorporating the FDE Prediction Program. This does not constitute an operational approval.

Navigation is accomplished using the WGS-84 (NAD-83) coordinate reference datum. Navigation data is based upon use of only the Global Positioning System (GPS) operated by the United States of America.

Aircraft Make: Aviation Design GARMIN GNS 530 VHF Communications
 Aircraft Model: A 92-11245 Transceiver / VOR/ILS Receiver / GPS Receiver
 Aircraft Serial Number: 014

- (c) Use of the GNS 530 VOR/ILS receiver to fly approaches not approved for GPS requires VOR/ILS navigation data to be present on the external indicator.
- (d) When an alternate airport is required by the applicable operating rules, it must be served by an approach based on other than GPS or Loran-C navigation, the aircraft must have the operational equipment capable of using that navigation aid, and the required navigation aid must be operational.
- (e) VNAV information may be utilized for advisory information only. Use of VNAV information for Instrument Approach Procedures does not guarantee Step-Down Fix altitude protection, or arrival at approach minimums in normal position to land.

5. If not previously defined, the following default settings must be made in the "SETUP" menu of the GNS 530 prior to operation (refer to Pilot's Guide for procedure if necessary):

- (a) $dis, spd \dots \dots \dots \frac{ft}{min}$ k_1 (sets navigation units to "nautical miles" and "knots")
- (b) $alt, vs \dots \dots \dots f, ftm$ (sets altitude units to "feet" and "feet per minute")
- (c) $map datum \dots \dots \dots WGS 84$ (sets map datum to WGS-84, see note below)
- (d) $posn \dots \dots \dots deg-min$ (sets navigation grid units to decimal minutes)

NOTE: In some areas outside the United States, datums other than WGS-84 or NAD-83 may be used. If the GNS 530 is authorized for use by the appropriate Airworthiness authority, the required geodetic datum must be set in the GNS 530 prior to its use for navigation.

**SECTION III
EMERGENCY PROCEDURES**

ABNORMAL PROCEDURES

- 1. If GARMIN GNS 530 navigation information is not available or invalid, utilize remaining operational navigation equipment as required.
- 2. If "RAIM POSITION WARNING" message is displayed the system will flag and no longer provide GPS based navigational guidance. The crew should revert to the GNS 530 VOR/ILS receiver or an alternate means of navigation other than the GNS 530's GPS Receiver.
- 3. If "RAIM IS NOT AVAILABLE" message is displayed in the enroute, terminal, or initial approach phase of flight, continue to navigate using the GPS equipment or revert to an alternate means of navigation other than the GNS 530's GPS receiver appropriate to the route

Aircraft Make: Aviation Design GARMIN GNS 530 VHF Communications
 Aircraft Model: A 92-11245 Transceiver / VOR/ILS Receiver / GPS Receiver
 Aircraft Serial Number: 014

and phase of flight. When continuing to use GPS navigation, position must be verified every 15 minutes using the GNS 530's VOR/ILS receiver or another IFR-approved navigation system.

- 4. If "RAIM IS NOT AVAILABLE" message is displayed while on the final approach segment, GPS based navigation will continue for up to 5 minutes with approach CDI sensitivity (0.3 nautical mile). After 5 minutes the system will flag and no longer provide course guidance with approach sensitivity. Missed approach course guidance may still be available with 1 nautical mile CDI sensitivity by executing the missed approach.
- 5. In an in-flight emergency, depressing and holding the Comm transfer button for 2 seconds will select the emergency frequency of 121.500 Mhz into the "Active" frequency window.

**SECTION IV
NORMAL PROCEDURES**

1. DETAILED OPERATING PROCEDURES

Normal operating procedures are described in the GARMIN GNS 530 Pilot's Guide, P/N 190-00181-00, Rev. A, dated April 2000 or later appropriate revision.

2. PILOTS DISPLAY

The GNS 530 System data will appear on the Pilot's CDI/HSI. The source of data is either GPS or VLOC as annunciated on the display above the CDI key.

NOTE: It is the pilot's responsibility to assure that published or assigned procedures are correctly complied with. Course guidance is not provided for all possible ARINC 424 leg types. See the GNS 530 Pilot's Guide for detailed operating procedures regarding navigation capabilities for specific ARINC 424 leg types.

Aircraft Make: Garmin GARMIN GNS 530 VHF Communications
Transceiver / VOR/ILS Receiver / GPS Receiver
Aircraft Model: A 92-1226
Aircraft Serial Number: 014

Aircraft Make: Garmin GARMIN GNS 530 VHF Communications
Transceiver / VOR/ILS Receiver / GPS Receiver
Aircraft Model: A 92-1226
Aircraft Serial Number: 014

regarding the interface of the GNS 530 with the TAS, refer to the FAA Approved Flight Manual Supplement for the TAS, the Pilot's Guide for the TAS and the GNS 530 Pilot's Guide.

8. DISPLAY OF TRAFFIC INFORMATION SERVICE DATA

TIS surveillance data unlinked by Air Traffic Control (ATC) radar through the GTX 330 Mode S Transponder will appear on the moving map and traffic display pages of the GNS 530. For detailed operating instructions regarding the interface of the GNS 530 with the GTX 330, refer to the GNS 530 Pilot's Guide Addendum for the TIS System interface.

**SECTION V
PERFORMANCE**

No change.

**SECTION VI
WEIGHT AND BALANCE**

See current weight and balance data.

**SECTION VII
AIRPLANE & SYSTEM DESCRIPTIONS**

See GNS 530 Pilot's Guide for a complete description of the GNS 530 system.

3. AUTOPILOT/FLIGHT DIRECTOR OPERATION

Coupling of the GNS 530 System steering information to the autopilot/flight director can be accomplished by engaging the autopilot/flight director in the NAV or APR mode.

When the autopilot/flight director system is using course information supplied by the GNS 530 System and the course pointer is not automatically driven to the desired track, the course pointer on the HSI must be manually set to the desired track (DTK) indicated by the GNS 530. For detailed autopilot/flight director operational instructions, refer to the FAA Approved Flight Manual Supplement for the autopilot/flight director.

4. CROSSFILL OPERATIONS

For dual GNC 500 Product Series or GNC 500/GNC 400 Product Series installations, crossfill capabilities exist between the number one and number two Systems. Refer to the GARMIN GNS 530 Pilot's Guide for detailed crossfill operating instructions.

5. AUTOMATIC LOCALIZER COURSE CAPTURE

By default, the GNS 530 automatic localizer course capture feature is enabled. This feature provides a method for system navigation data present on the external indicators to be switched automatically from GPS guidance to localizer / glide slope guidance as the aircraft approaches the localizer course inbound to the final approach fix. If an offset from the final approach course is being flown, it is possible that the automatic switch from GPS course guidance to localizer / glide slope course guidance will not occur. It is the pilot's responsibility to ensure correct system navigation data is present on the external indicator before continuing a localizer based approach beyond the final approach fix. Refer to the GNS 530 Pilot's Guide for detailed operating instructions.

6. DISPLAY OF LIGHTNING STRIKE DATA

For installations that interface the BFGoodrich WX-500 Stormscope and the GNS 530, lightning strike data detected by the WX-500 will appear on the GNS 530. For detailed operating instructions regarding the interface of the GNS 530 with the WX-500, refer to the WX-500 Pilot's Guide and the GNS 530 Pilot's Guide for the WX-500 Stormscope interface.

7. DISPLAY OF TRAFFIC ADVISORY DATA

For installations that interface a Traffic Advisory System (TAS) and the GNS 530, traffic data detected by the TAS will appear on the GNS 530. For detailed operating instructions